De-greying agent

PRODUCT DESCRIPTION

Cleans effectively and removes the greyish tinge by lightening the wood. Works on both hardwoods and softwoods thanks to its active ingredients derived from coconut fatty acid and nature-identical oxalic acid.

SCOPE OF APPLICATION	Garden furniture made from hardwood and softwood. Also suitable for weathered decking, etc.
PACK SIZES	1 l
PROCESSING	Shake briefly before use and apply generously to the wooden surfaces with a brush. Do not apply in direct sunlight, as this will cause the grey remover to dry too quickly. If temperatures are high, dampen the wood slightly beforehand if possible. Leave to work for 10–15 minutes. Rub off with a stiff brush or abrasive pad using water, then rinse off. To neutralise the product and remove any dirt, rinse thoroughly with water and then allow the wood to dry completely. After this treatment, the wood will be rough and leached. Sand the surfaces thoroughly before further treatment and proceed accordingly.
CONSUMPTION	This varies depending on the wood's absorbency, but at least 100 ml/m^2 is required.
DRYING TIME	1–2 days, depending on the weather.
SUBSURFACE	All pieces of timber, roughly cleaned of dirt.
INGREDIENTS	Water, oxalic acid, methylcellulose, plant-based emulsifier
VOC SAFETY NOTICE	**No solvents**
STORAGE	Store in a tightly sealed container in a dry, cool place, away from frost.

SHELF LIFE	Unopened, it will keep for at least 4 years.
DISPOSAL	Do not dispose of any paint or solvent residues into the sewage system or onto the ground, or allow them to enter these systems during application! Fully dried residues of this product can be disposed of as household or general waste; empty tins (tinplate) should be placed in the relevant local recycling bins or yellow bags/bins (Green Dot).
SAFETY INSTRUCTIONS	Causes skin irritation. Causes serious eye irritation. If medical advice is needed, have the container or label to hand. Keep out of the reach of children.
DISCLAIMER	The information contained in this publication is based on our careful research and testing and is provided to the best of our knowledge. It is intended solely for the information of our customers; however, it does not exempt them from carrying out their own independent assessment of the products described to determine their suitability for the intended processes and purposes, nor does it exempt them from the risk of infringing any third-party intellectual property rights. This information is therefore non-binding and, in particular, does not constitute any warranty of quality within the meaning of the law. We accept no liability for the accuracy and completeness of the information contained in this publication, nor for any other technical advice we may provide. In addition, we refer you to our General Terms and Conditions, which are available on request.
CONTACT	Hermann Sachse GmbH Unter den Linden 10 10117 Berlin Mobil: +49 (0) 30 / 346 558 515 E-Mail: hallo@le-tonkinois.de

To achieve the best possible results, please refer to the technical data sheets for all products used. The information provided is based on our current knowledge and experience. However, it does not constitute a guarantee of product properties and does not give rise to any contractual relationship. Upon publication of this technical data sheet, all previous information ceases to be valid.